



INSTALLATION INSTRUCTION

<p>1</p>	<p>2</p>	<p>3</p>
<p>4</p> <p>Rotatable $\pm 90^\circ$</p>	<p>5</p>	
<p>Parts:</p>	<p>Connect in parallel</p>	